



Custom Computer Desk

Written By: Randy Kangas

SUMMARY

Oak door slabs can be recycled into furniture you can use for many years to come and even pass down to future generations of your family.

Step 1 — Custom Computer Desk



- Nine free oak door slabs.

Step 2



- Measure your walls in the desk location to determine your overall desk size.

Step 3



- Measure the sizes of your devices and start designing the layout of your custom desk.
- Next, start cutting all your parts to the correct sizes.
- Sand all of the wooden pieces smooth.
- Finish with stain or paint them whatever color you'd like them to be.

Step 4



- Assemble all the finished parts.
- Add your home electronic devices and run all the wires out of sight. We're going for a very clean, crisp, and sharp look here.

This document was last generated on 2012-11-01 03:10:32 AM.